
Sunroof , (3FD),(3FE) From January 2011



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.






## Sunroof Adjuster, Power Sunroof Control Module, Sunroof

- EX4 Sunroof Adjuster
- E325 Sunroof Button
- E582 Sunroof Tilt Button 1
- J245 Power Sunroof Control Module
- Comfort System Central Control Module

- Fuse 7 (On Fuse Panel B)
- SB12 Fuse 12 (On Fuse Panel B)
- 5-Pin Connector
- T10b 10-Pin Connector
- T32a 32-Pin Connector
- 32-Pin Connector
- Sunroof Motor
- Ground Connection on A-Pillar, Lower Left
- Ground Connection 4 (in Main Wiring Harness)
- Lin Bus Connection 4 (in Main Wiring Harness)
- Connection 58s (in Main Wiring Harness) 1
- Refer to Applicable Wiring Diagram for Fuse Positions
- From June 2014



## Sunroof Button, Power Sunroof Control Module, Sunroof Motor

- E325 Sunroof Button
- J245 Power Sunroof Control Module
- ST2 Fuse Panel 2
- ST3 Fuse Panel 3
- SB7 Fuse 7 (On Fuse Panel B)
- SB11 Fuse 11 (On Fuse Panel B)
- SB12 Fuse 12 (On Fuse Panel B)
- SF12 Fuse 12 (On Fuse Panel F)
- T6g 6-Pin Connector
- V1 Sunroof Motor
- \* Refer to Applicable Wiring Diagram for Fuse Positions
- \*2 Avant
- \*3 From June 2014